










### LADERS

<p><b>DCB090-XJ</b></p>  <p>USB XR laadadapter (voor 12V / 14.4V / 18V)</p>	<p><b>DCB115-QW</b></p>  <p>XR multivoltage lader</p>	<p><b>DCB1104-QW</b></p>  <p>XR multivoltage lader</p>	<p><b>DCB119-XJ</b></p>  <p>XR multiautolader (voor 12V / 14.4V / 18V)</p>
<p><b>DCB117-QW</b></p>  <p>18V / 54V XR FLEXVOLT snellader</p>	<p><b>DCB132-QW</b></p>  <p>18V / 54V XR FLEXVOLT Duolader</p>	<p><b>DCB104-QW</b></p>  <p>12V / 18V / 54V XR FLEXVOLT 4 port snellader</p>	<p><b>DCB094K-QW</b></p>  <p>18V XR USB laadadapter</p>

### STARTER SETS

<p><b>DCB1102E2-QW</b></p>  <p>2x 18V compacte POWERSTACK accu's + snellader</p>	<p><b>DCB1104D2-QW</b></p>  <p>2x 18V 2.0Ah accu's + snellader</p>	<p><b>DCB1104P2-QW</b></p>  <p>2x 18V 5.0Ah accu's + snellader</p>	<p><b>DCB1104P3-QW</b></p>  <p>3x 18V 5.0Ah accu's + snellader</p>	
<p><b>DCB118T2-QW</b></p>  <p>2x XR FLEXVOLT 6.0Ah accu's + snellader</p>	<p><b>DCB132T2-QW</b></p>  <p>2x XR FLEXVOLT 6.0Ah accu's + duolader</p>	<p><b>DCB118X2-QW</b></p>  <p>2x XR FLEXVOLT 9.0Ah accu's + snellader</p>	<p><b>DCB132X2-QW</b></p>  <p>2x XR FLEXVOLT 9.0Ah accu's + duolader</p>	<p><b>DCB118Y2-QW</b></p>  <p>2x XR FLEXVOLT 12.0Ah accu's + snellader</p>